

Initiating Search

November 10, 2025, 4:21 PM

• Search:

CAS Lexicon Search:

Transhalogenation - Preferred Concept

Search Tasks

Task	Result Type	View
Returned Reference Results from CAS Lexicon (579)	 References	View Results
Exported: Retrieved Related Reaction Results + Filters (250)	 Reactions	View Results
Filtered By:		
Yield:	90-100%, 80-89%, 70-79%	
Document Type:	Journal	

Copyright © 2025 American Chemical Society (ACS). All Rights Reserved.

Internal use only. Redistribution is subject to the terms of your CAS SciFinder License Agreement and CAS information Use Policies.

Reactions (50)

[View in CAS SciFinder](#)

Scheme 1 (1 Reaction)

Steps: 1 Yield: 100%


 Suppliers (34)

31-174-CAS-14443138

Steps: 1 Yield: 100%

Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction

By: Klapars, Artis; et al


Journal of the American Chemical Society (2002), 124(50), 14844-14845.

1.1 **Reagents:** Sodium iodide
Catalysts: Cuprous iodide, *trans*-*N,N*-Dimethyl-1,2-cyclohexanediamine
Solvents: 1,4-Dioxane; 24 h, 110 °C; 110 °C → rt

Experimental Protocols

Scheme 2 (1 Reaction)

Steps: 1 Yield: 100%


 Suppliers (62)

 Suppliers (86)

31-174-CAS-14529133

Steps: 1 Yield: 100%

Phosphonium ionic liquids as highly thermal stable and efficient phase transfer catalysts for solid-liquid Halex reactions

By: Fan, Ao; et al

Catalysis Today (2012), 198(1), 300-304.

1.1 **Reagents:** Potassium fluoride
Catalysts: Trihexyl(tetradecyl)phosphonium tetrafluoroborate
Solvents: Dimethyl sulfoxide; 1.8 h, 180 °C

Scheme 3 (4 Reactions)

Steps: 1 Yield: 100%



31-174-CAS-5970042

Steps: 1 Yield: 100%

Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp}2-O Bond Forming Reactions

By: Serra, Jordi; et al

Journal of the American Chemical Society (2015), 137(41), 13389-13397.


1.1 **Reagents:** 1,3,5-Trimethoxybenzene, Silver fluoride
Catalysts: Chloro(triphenylphosphine)gold
Solvents: Acetonitrile-*d*₃; 48 h, 40 °C

Experimental Protocols

31-174-CAS-12366314 Steps: 1 Yield: 100% 1.1 Reagents: 1,3,5-Trimethoxybenzene, Silver fluoride Solvents: Acetonitrile- <i>d</i> ₃ ; 48 h, 40 °C Experimental Protocols	Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp}²-O Bond Forming Reactions By: Serra, Jordi; et al Journal of the American Chemical Society (2015), 137(41), 13389-13397.
31-174-CAS-10236393 Steps: 1 Yield: 100% 1.1 Reagents: 1,3,5-Trimethoxybenzene, Silver fluoride Catalysts: Gold(1+), (acetonitrile)[1,3-bis[2,6-bis(1-methylethyl)phenyl]-1,3-dihydro-2 <i>H</i> -imidazol-2-ylidene]-, (<i>OC</i> -6-11)-hexafluoroantimonate(1-) (1:1) Solvents: Acetonitrile- <i>d</i> ₃ ; 6 h, 40 °C Experimental Protocols	Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp}²-O Bond Forming Reactions By: Serra, Jordi; et al Journal of the American Chemical Society (2015), 137(41), 13389-13397.
31-174-CAS-8102564 Steps: 1 Yield: 100% 1.1 Reagents: 1,3,5-Trimethoxybenzene, Silver fluoride Catalysts: [1,1,1-Trifluoro- <i>N</i> -[(trifluoromethyl)sulfonyl]methanesulfonamido-κ <i>M</i>](triphenylphosphine)gold Solvents: Acetonitrile- <i>d</i> ₃ ; 48 h, 40 °C Experimental Protocols	Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp}²-O Bond Forming Reactions By: Serra, Jordi; et al Journal of the American Chemical Society (2015), 137(41), 13389-13397.

Scheme 4 (1 Reaction)


Steps: 1 Yield: 100%



31-174-CAS-16538737 Steps: 1 Yield: 100% 1.1 Reagents: Lithium chloride Solvents: Dimethyl sulfoxide; 48 h, 80 °C Experimental Protocols	Computational and Experimental Studies of Regioselective S_NAr Halide Exchange (Halex) Reactions of Pentachloropyridine By: Froese, Robert D. J.; et al Journal of Organic Chemistry (2016), 81(22), 10672-10682.
--	--

Scheme 5 (2 Reactions)

Steps: 1 Yield: 97-100%




31-174-CAS-11906218 Steps: 1 Yield: 100% 1.1 Reagents: Potassium fluoride Catalysts: Bis(triphenylphosphine)iminium chloride Solvents: Dimethyl sulfoxide; 8 h, 150 °C; cooled Experimental Protocols	Efficient phosphorus catalysts for the halogen-exchange (Halex) reaction By: Lacour, Marie-Agnes; et al Advanced Synthesis & Catalysis (2008), 350(17), 2677-2682.
--	---

31-174-CAS-7687920	Steps: 1 Yield: 97%	Synthesis of 3-chloro-4-fluoronitrobenzene promoted by microwave irradiation
1.1 Reagents: Potassium fluoride Catalysts: Antimony trichloride Solvents: Dimethyl sulfoxide; 10 min, heated		By: Luo, Jun; et al Jingxi Huagong Zhongjianti (2007), 37(1), 30-33.

Scheme 6 (1 Reaction)


Steps: 1 Yield: 100%



31-174-CAS-15457454	Steps: 1 Yield: 100%	Efficient phosphorus catalysts for the halogen-exchange (Halex) reaction
1.1 Reagents: Potassium fluoride Catalysts: Bis(triphenylphosphine)iminium chloride Solvents: Dimethyl sulfoxide; 8 h, 150 °C; cooled		By: Lacour, Marie-Agnes; et al Advanced Synthesis & Catalysis (2008), 350(17), 2677-2682.
Experimental Protocols		

Scheme 7 (1 Reaction)


Steps: 1 Yield: 99%



31-614-CAS-33927301	Steps: 1 Yield: 99%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Tetrabutylammonium bromide Solvents: 1,4-Dioxane; 36 h, rt		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 8 (1 Reaction)


Steps: 1 Yield: 99%



31-614-CAS-33927278	Steps: 1 Yield: 99%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: Cyclopentyl methyl ether; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Sodium iodide Solvents: Cyclopentyl methyl ether; 36 h, 50 °C		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 9 (1 Reaction)

Steps: 1 Yield: 99%




Suppliers (87)

Suppliers (67)

31-614-CAS-33927315	Steps: 1 Yield: 99%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Benzyltriethylammonium chloride Solvents: 1,4-Dioxane; 24 h, rt		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 10 (1 Reaction)

Steps: 1 Yield: 99%




Suppliers (68)

Suppliers (78)

31-614-CAS-33927294	Steps: 1 Yield: 99%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Tetrabutylammonium bromide Solvents: 1,4-Dioxane; 36 h, rt		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 11 (1 Reaction)

Steps: 1 Yield: 99%



Suppliers (76)

Suppliers (75)

31-614-CAS-33927287

Steps: 1 Yield: 99%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: Cyclopentyl methyl ether; 10 min, rt

1.2 **Reagents:** Sodium iodide

Solvents: Cyclopentyl methyl ether; 36 h, 50 °C

1.3 **Reagents:** Water; rt


Experimental Protocols

By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Scheme 12 (1 Reaction)

Steps: 1 Yield: 99%



Suppliers (85)

Suppliers (59)

31-614-CAS-33927307

Steps: 1 Yield: 99%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: 1,4-Dioxane; 10 min, rt

1.2 **Reagents:** Benzyltriethylammonium chloride

Solvents: 1,4-Dioxane; 36 h, rt

1.3 **Reagents:** Water; rt


Experimental Protocols

By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Scheme 13 (1 Reaction)

Steps: 1 Yield: 99%




Suppliers (50)

Suppliers (11)

31-174-CAS-3475487	Steps: 1 Yield: 99%	Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction
1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i> - <i>N,N</i> -Dimethyl-1,2-cyclohexanediamine Solvents: 1-Pentanol; 40 h, 130 °C; 130 °C → rt		By: Klapars, Artis; et al Journal of the American Chemical Society (2002), 124(50), 14844-14845.
1.2 Solvents: Hexane		
Experimental Protocols		

Scheme 14 (1 Reaction)

Steps: 1 Yield: 99%




Suppliers (92)

Suppliers (80)

31-614-CAS-33927274	Steps: 1 Yield: 99%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: Cyclopentyl methyl ether; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Sodium iodide Solvents: Cyclopentyl methyl ether; 36 h, 50 °C		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 15 (1 Reaction)

Steps: 1 Yield: 99%




Suppliers (85)

Suppliers (91)

31-614-CAS-33927311	Steps: 1 Yield: 99%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Tetrabutylammonium bromide Solvents: 1,4-Dioxane; 36 h, 50 °C		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 16 (1 Reaction)

Steps: 1 Yield: 99%



Suppliers (89)

Suppliers (85)

31-614-CAS-33927271

Steps: 1 Yield: 99%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: Cyclopentyl methyl ether; 10 min, rt

1.2 **Reagents:** Sodium iodide

Solvents: Cyclopentyl methyl ether; 12 h, 50 °C

1.3 **Reagents:** Water; rt


Experimental Protocols

By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Scheme 17 (3 Reactions)

Steps: 1 Yield: 99%



31-174-CAS-6303381

Steps: 1 Yield: 99%

Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp2}-O Bond Forming Reactions

1.1 **Reagents:** 1,3,5-Trimethoxybenzene, Tetrabutylammonium chloride

Catalysts: [1,1,1-Trifluoro-*N*-[(trifluoromethyl)sulfonyl]methanesulfonamido-κ*M*](triphenylphosphine)gold

Solvents: Acetonitrile-*d*₃; 60 h, 40 °C

Experimental Protocols

By: Serra, Jordi; et al

Journal of the American Chemical Society (2015), 137(41), 13389-13397.

31-174-CAS-8427690

Steps: 1 Yield: 99%

Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp2}-O Bond Forming Reactions

1.1 **Reagents:** 1,3,5-Trimethoxybenzene, Tetrabutylammonium chloride

Catalysts: Gold(1+), (acetonitrile)[1,3-bis[2,6-bis(1-methylethyl)phenyl]-1,3-dihydro-2*H*-imidazol-2-ylidene]-, (*OC*-6-11)-hexafluoroantimonate(1-)(1:1)

Solvents: Acetonitrile-*d*₃; 12 h, 40 °C

Experimental Protocols

By: Serra, Jordi; et al

Journal of the American Chemical Society (2015), 137(41), 13389-13397.

31-174-CAS-2651901

Steps: 1 Yield: 99%

Nucleophilic Aryl Fluorination and Aryl Halide Exchange Mediated by a Cu^I/Cu^{III} Catalytic Cycle

1.1 **Reagents:** Tetrabutylammonium chloride

Catalysts: Copper(1+), tetrakis(acetonitrile)-, (*7*-4)-, 1,1,1-trifluoromethanesulfonate (1:1)

Solvents: Acetonitrile-*d*₃; 2 h, 25 °C


Experimental Protocols

By: Casitas, Alicia; et al

Journal of the American Chemical Society (2011), 133(48), 19386-19392.

Scheme 18 (2 Reactions)

Steps: 1 Yield: 97-99%



Suppliers (65)

Suppliers (99)

31-174-CAS-643431

Steps: 1 Yield: 99%

Efficient phosphorus catalysts for the halogen-exchange (Halex) reaction

1.1 **Reagents:** Potassium fluoride
Catalysts: Bis(triphenylphosphine)iminium chloride
Solvents: Dimethyl sulfoxide; 8 h, 150 °C; cooled

By: Lacour, Marie-Agnes; et al

Advanced Synthesis & Catalysis (2008), 350(17), 2677-2682.

Experimental Protocols

31-174-CAS-10555300

Steps: 1 Yield: 97%

Phosphonium ionic liquids as highly thermal stable and efficient phase transfer catalysts for solid-liquid Halex reactions


1.1 **Reagents:** Potassium fluoride
Catalysts: Trihexyl(tetradecyl)phosphonium tetrafluoroborate
Solvents: Dimethyl sulfoxide; 9 h, 180 °C

By: Fan, Ao; et al

Catalysis Today (2012), 198(1), 300-304.

Scheme 19 (3 Reactions)

Steps: 1 Yield: 99%



31-174-CAS-11859178

Steps: 1 Yield: 99%

Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp2}-O Bond Forming Reactions

1.1 **Reagents:** 1,3,5-Trimethoxybenzene, Tetrabutylammonium chloride
Catalysts: Gold(1+), (acetonitrile)[1,3-bis[2,6-bis(1-methylethyl)phenyl]-1,3-dihydro-2H-imidazol-2-ylidene]-, (OC-6-11)-hexafluoroantimonate(1-) (1:1)
Solvents: Acetonitrile-*d*₃; 6 h, 40 °C

By: Serra, Jordi; et al

Journal of the American Chemical Society (2015), 137(41), 13389-13397.

Experimental Protocols

31-174-CAS-9731251

Steps: 1 Yield: 99%

Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp2}-O Bond Forming Reactions

1.1 **Reagents:** 1,3,5-Trimethoxybenzene, Tetrabutylammonium chloride
Catalysts: Chloro(triphenylphosphine)gold
Solvents: Acetonitrile-*d*₃; 48 h, 40 °C

By: Serra, Jordi; et al

Journal of the American Chemical Society (2015), 137(41), 13389-13397.

Experimental Protocols

31-174-CAS-11772369

Steps: 1 Yield: 99%

Nucleophilic Aryl Fluorination and Aryl Halide Exchange Mediated by a Cu^I/Cu^{III} Catalytic Cycle

1.1 **Reagents:** Tetrabutylammonium chloride
Catalysts: Copper(1+), tetrakis(acetonitrile)-, (7-4)-, 1,1,1-trifluoromethanesulfonate (1:1)
Solvents: Acetonitrile-*d*₃; 1.5 h, 25 °C


By: Casitas, Alicia; et al

Journal of the American Chemical Society (2011), 133(48), 19386-19392.

Experimental Protocols

Scheme 20 (1 Reaction)

Steps: 1 Yield: 99%



Suppliers (85)

Suppliers (79)

31-614-CAS-33927299

Steps: 1 Yield: 99%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: 1,4-Dioxane; 10 min, rt

1.2 **Reagents:** Tetrabutylammonium bromide

Solvents: 1,4-Dioxane; 36 h, rt

1.3 **Reagents:** Water; rt


Experimental Protocols

By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Scheme 21 (1 Reaction)

Steps: 1 Yield: 99%



Suppliers (67)

Suppliers (14)

31-614-CAS-33927273

Steps: 1 Yield: 99%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: Cyclopentyl methyl ether; 10 min, rt

1.2 **Reagents:** Sodium iodide

Solvents: Cyclopentyl methyl ether; 36 h, 50 °C

1.3 **Reagents:** Water; rt


Experimental Protocols

By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Scheme 22 (1 Reaction)

Steps: 1 Yield: 98%




Suppliers (80)

Suppliers (19)

31-174-CAS-4451592	Steps: 1 Yield: 98%	Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction
1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i> - <i>N,N</i> -Dimethyl-1,2-cyclohexanediamine Solvents: 1,4-Dioxane; 24 h, 110 °C; 110 °C → rt	By: Klapars, Artis; et al Journal of the American Chemical Society (2002), 124(50), 14844-14845.	
1.2 Reagents: Ammonia Solvents: Water; 15 min, rt; 15 h, rt		
Experimental Protocols		

Scheme 23 (1 Reaction)


Steps: 1 Yield: 98%



31-174-CAS-7825553	Steps: 1 Yield: 98%	Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp2}-O Bond Forming Reactions
1.1 Reagents: 1,3,5-Trimethoxybenzene, Silver fluoride Catalysts: Gold(1+), (acetonitrile)[1,3-bis[2,6-bis(1-methylethyl)phenyl]-1,3-dihydro-2 <i>H</i> -imidazol-2-ylidene]-, (<i>OC</i> -6-11)-hexafluoroantimonate(1-) (1:1) Solvents: Acetonitrile- <i>d</i> ₃ ; 12 h, 70 °C	By: Serra, Jordi; et al Journal of the American Chemical Society (2015), 137(41), 13389-13397.	
Experimental Protocols		

Scheme 24 (1 Reaction)

Steps: 1 Yield: 98%



Suppliers (88)

Suppliers (60)

31-174-CAS-12972100	Steps: 1 Yield: 98%	Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction
1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i> - <i>N,N</i> -Dimethyl-1,2-cyclohexanediamine Solvents: 1,4-Dioxane; 24 h, 110 °C; 110 °C → rt	By: Klapars, Artis; et al Journal of the American Chemical Society (2002), 124(50), 14844-14845.	
Experimental Protocols		

Scheme 25 (1 Reaction)


Steps: 1 Yield: 98%



31-174-CAS-12004546	Steps: 1 Yield: 98%	Nucleophilic Aryl Fluorination and Aryl Halide Exchange Mediated by a Cu^I/Cu^{III} Catalytic Cycle
1.1 Reagents: Silver fluoride Catalysts: Copper(1+), tetrakis(acetonitrile)-, (7-4)-, 1,1,1-trifluoromethanesulfonate (1:1) Solvents: Acetone, Acetonitrile; 12 h, 298 K		By: Casitas, Alicia; et al Journal of the American Chemical Society (2011), 133(48), 19386-19392.
Experimental Protocols		

Scheme 26 (1 Reaction)

Steps: 1 Yield: 98%




Suppliers (5)

Suppliers (7)

31-174-CAS-15357477	Steps: 1 Yield: 98%	Green synthesis of 6-fluoropurine under microwave irradiation
1.1 Reagents: Potassium fluoride Catalysts: Triethylamine Solvents: 1-Butyl-3-methylimidazolium tetrafluoroborate; 10 min, 100 °C		By: Xu, Shao-hong; et al Huaxue Shiji (2010), 32(9), 862-864.

Scheme 27 (1 Reaction)

Steps: 1 Yield: 98%




Suppliers (92)

Suppliers (91)

31-614-CAS-33927291	Steps: 1 Yield: 98%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Tetrabutylammonium bromide Solvents: 1,4-Dioxane; 36 h, rt		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 28 (1 Reaction)

Steps: 1 Yield: 98%




Suppliers (85)

Suppliers (73)

31-614-CAS-33927317	Steps: 1 Yield: 98%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Benzyltriethylammonium chloride Solvents: 1,4-Dioxane; 36 h, 60 °C		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 29 (1 Reaction)


Steps: 1 Yield: 98%



31-174-CAS-3525315	Steps: 1 Yield: 98%	Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction
1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i> - <i>N,N</i> -Dimethyl-1,2-cyclohexanediamine Solvents: 1,4-Dioxane; 24 h, 110 °C; 110 °C → rt		By: Klapars, Artis; et al Journal of the American Chemical Society (2002), 124(50), 14844-14845.
Experimental Protocols		

Scheme 30 (1 Reaction)


Steps: 1 Yield: 98%



31-614-CAS-33927283	Steps: 1 Yield: 98%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: Cyclopentyl methyl ether; 10 min, rt		By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
1.2 Reagents: Sodium iodide Solvents: Cyclopentyl methyl ether; 36 h, 50 °C		
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 31 (1 Reaction)


Steps: 1 Yield: 97%



31-174-CAS-2379465	Steps: 1 Yield: 97%	A convenient synthetic approach to 1,5-diiodonaphthalene derivatives
1.1 Reagents: Butyllithium Solvents: Tetrahydrofuran, Hexane		By: Pan, Yongchun; et al
1.2 Reagents: Iodine Solvents: Tetrahydrofuran		Tetrahedron Letters (2000), 41(23), 4537-4540.

Scheme 32 (1 Reaction)

Steps: 1 Yield: 97%



Suppliers (87)

Suppliers (84)

31-614-CAS-33927296	Steps: 1 Yield: 97%	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange
1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: 1,4-Dioxane; 10 min, rt		By: Feng, Yunhui; et al
1.2 Reagents: Tetrabutylammonium bromide Solvents: 1,4-Dioxane; 12 h, rt		ACS Catalysis (2022), 12(18), 11089-11096.
1.3 Reagents: Water; rt		
Experimental Protocols		

Scheme 33 (1 Reaction)

Steps: 1 Yield: 97%



31-174-CAS-14134337	Steps: 1 Yield: 97%	Nucleophilic Aryl Fluorination and Aryl Halide Exchange Mediated by a Cu^I/Cu^{III} Catalytic Cycle
1.1 Reagents: Silver fluoride Catalysts: Copper(1+), tetrakis(acetonitrile)-, (7-4)-, 1,1,1-trifluoromethanesulfonate (1:1) Solvents: Acetone, Acetonitrile; 24 h, 298 K		By: Casitas, Alicia; et al
Experimental Protocols		Journal of the American Chemical Society (2011), 133(48), 19386-19392.

Scheme 34 (1 Reaction)


Steps: 1 Yield: 97%



31-174-CAS-13981989 Steps: 1 Yield: 97% 1.1 Reagents: 1,3,5-Trimethoxybenzene, Sodium bromide Catalysts: Gold(1+), (acetonitrile)[1,3-bis[2,6-bis(1-methylethyl)phenyl]-1,3-dihydro-2<i>H</i>-imidazol-2-ylidene]-, (<i>OC</i>-6-11)-hexafluoroantimonate(1-) (1:1) Solvents: Acetonitrile-<i>d</i>₃; 30 h, 70 °C Experimental Protocols	Oxidant-Free Au(I)-Catalyzed Halide Exchange and C_{sp}²-O Bond Forming Reactions By: Serra, Jordi; et al Journal of the American Chemical Society (2015), 137(41), 13389-13397.
---	---

Scheme 35 (1 Reaction)

Steps: 1 Yield: 97%




Suppliers (58)

Suppliers (73)

31-614-CAS-33927281 Steps: 1 Yield: 97% 1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: Cyclopentyl methyl ether; 10 min, rt 1.2 Reagents: Sodium iodide Solvents: Cyclopentyl methyl ether; 36 h, 50 °C 1.3 Reagents: Water; rt Experimental Protocols	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
---	--

Scheme 36 (1 Reaction)

Steps: 1 Yield: 97%




Suppliers (97)

Suppliers (91)

31-614-CAS-33927267 Steps: 1 Yield: 97% 1.1 Catalysts: Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine Solvents: Cyclopentyl methyl ether; 10 min, rt 1.2 Reagents: Sodium iodide Solvents: Cyclopentyl methyl ether; 36 h, 50 °C 1.3 Reagents: Water; rt Experimental Protocols	Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange By: Feng, Yunhui; et al ACS Catalysis (2022), 12(18), 11089-11096.
---	--

Scheme 37 (1 Reaction)

Steps: 1 Yield: 97%



Suppliers (80)

Suppliers (89)

31-614-CAS-33927309

Steps: 1 Yield: 97%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: 1,4-Dioxane; 10 min, rt

1.2 **Reagents:** Benzyltriethylammonium chloride

Solvents: 1,4-Dioxane; 48 h, rt

1.3 **Reagents:** Water; rt


By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Experimental Protocols

Scheme 38 (1 Reaction)

Steps: 1 Yield: 97%



Suppliers (74)

Suppliers (86)

31-614-CAS-33927312

Steps: 1 Yield: 97%

Light-Promoted Nickel-Catalyzed Aromatic Halogen Exchange

1.1 **Catalysts:** Bis(1,5-cyclooctadiene)nickel, 4,4'-Bis(1,1-dimethylethyl)-2,2'-bipyridine

Solvents: 1,4-Dioxane; 10 min, rt

1.2 **Reagents:** Tetrabutylammonium bromide

Solvents: 1,4-Dioxane; 48 h, 50 °C

1.3 **Reagents:** Water; rt


By: Feng, Yunhui; et al

ACS Catalysis (2022), 12(18), 11089-11096.

Experimental Protocols

Scheme 39 (1 Reaction)

Steps: 1 Yield: 97%




Suppliers (70)

Suppliers (68)

31-174-CAS-8715362 Steps: 1 Yield: 97% 1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i>-<i>N,N</i>-Dimethyl-1,2-cyclohexanediamine Solvents: 1,4-Dioxane; 24 h, 110 °C; 110 °C → rt 1.2 Reagents: Ammonia Solvents: Water; 15 min, rt; 15 h, rt Experimental Protocols	Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction By: Klapars, Artis; et al Journal of the American Chemical Society (2002), 124(50), 14844-14845.
---	--

Scheme 40 (1 Reaction)


Steps: 1 Yield: 97%



31-174-CAS-8061562 Steps: 1 Yield: 97% 1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i>-<i>N,N</i>-Dimethyl-1,2-cyclohexanediamine Solvents: 1,4-Dioxane; 24 h, 110 °C; 110 °C → rt Experimental Protocols	Copper-Catalyzed Halogen Exchange in Aryl Halides: An Aromatic Finkelstein Reaction By: Klapars, Artis; et al Journal of the American Chemical Society (2002), 124(50), 14844-14845.
--	--

Scheme 41 (1 Reaction)

Steps: 1 Yield: 97%



31-174-CAS-7777506 Steps: 1 Yield: 97% 1.1 Reagents: Sodium iodide Catalysts: Cuprous iodide, <i>trans</i>-<i>N,N</i>-Dimethyl-1,2-cyclohexanediamine Solvents: Acetonitrile; 2 min, rt → 100 °C; 60 min, 100 °C Experimental Protocols	Hydrodehalogenation of Aryl Chlorides and Aryl Bromides Using a Microwave-Assisted, Copper-Catalyzed Concurrent Tandem Catalysis Methodology By: Cannon, Kathleen A.; et al Organometallics (2011), 30(15), 4067-4073.
--	--